



REPLACEMENT PARTS for ZETOR / URSUS BELARUS / ROMANIA / RUSSIAN / KRAZ / KAMAZ



Reliable Engineering House



ISO 9001:2008 CERTIFIED

Plot No. 8, Cama Industrial Estate, Goregaon (East),

Mumbai 400 063, INDIA.

Tel.: +91 - 22 - 2685 1428

+91 - 22 - 2685 1435

+91 - 22 - 2685 1438

Email: hercules@reliableengg.com ♦ sales@reliableengg.com

Website: www.reliableengg.com

REPLACEMENT PARTS



Part Nos. / Ref No. / Engine Name / Model are only given for cross reference.



These are few pages from our Catalogue

For our complete catalogue please contact us at

Email: hercules@reliableengg.com

CYL. LINER FOR ZETOR	CYL. LINER FOR ZETOR	
		
For ZETOR 5911 Bore: 102 mm	For ZETOR 8011 / 8611 Bore: 110 mm	

PISTON FOR BELARUS	PISTON FOR KAMAZ	PISTON FOR URSUS / ESCORT
		
For BELARUS MTZ 50 BORE: 110.00mm PT. NO. RINGS. 3.00+3.00+3.00+6.00+6.00	For KAMAZ TURBO Bore: 120.00mm PT. NO. Rings. 3.00 + 3.00 + 5.00	For URSUS / ESCORT 27 Bore: 102mm Pin: mm Rings:

PISTON FOR ZETOR	PISTON FOR ZETOR	PISTON FOR ZETOR
		
For ZETOR 5RV Bore: 95.00mm Rings. 3.00+3.00+3.00+5.00+5.00	For ZETOR 6911 Bore: 102.00 mm Pin-35 X 85mm Rings. 3.0 + 3.0 + 3.0 + 5.0	For Bore: mm Pin: mm Rings:

PISTON FOR ZETOR	PISTON FOR ZETOR	PISTON FOR ZETOR
		
For ZETOR 4701 / 6701 / 5911 CH-66, TL-116, Bore: 100mm Cavity -50mm dia, Pin-35 X 86mm Rings. 3.0 + 3.0 + 3.0 + 5.0	For ZETOR 6911 – Model 71 CH-66.5, TL-116.5, Bore: 102mm Cavity -47.5mm dia, Pin-35 X 85mm Rings. 3.0 + 3.0 + 3.0 + 5.0	For ZETOR 8011 / 8611 Alfin CH-76.3, TL-128.3, Bore: 110.00mm Cavity -55.9mm dia, Pin-40 X 93mm Ring. 3.0 + 3.0 + 6.0

CONNECTING ROD FOR ZETOR



For ZETOR 2011 / 3011 / 4011
URSUS 360, S4001 / 2V / 3V
HMT
OEM Part No.: 69010389, 46503230

CONNECTING ROD FOR ZETOR



For ZETOR GTCL
(For Crank with Counter Balance Weight)
OEM Part No.: 71010309

CONNECTING ROD FOR ZETOR



For ZETOR 5911
URSUS 385, Z8401
(Heavy Duty Engine)
OEM Part No.: 89003529

CONNECTING ROD FOR URSUS



For URSUS C - 330
ESCORT - 335 / ANDORIA S312C (42032100)
2 CYL.

ENGINE VALVES VALVE GUIDE, VALVE SEAT, VALVE TAPPET



REH NO.	ITEM		MAKE	MODEL	REF.NO./PART NO./DETAILS
82003	VALVE		BALARUS	MTZ 50	
82037	VALVE		ROMANIA	D-15	
82356	VALVE	IN	ROMANIA	UTB-650	103-02-117
82357	VALVE	EX	ROMANIA	UTB-650	103-02-118
82038	VALVE		RUSSIAN	T-62	
82068	VALVE	1 CYL.	RUSTON	YDA MK-I	1200 103117 / 1200 103118
82069	VALVE	1 CYL.	RUSTON	Y2DA MK-II	2200 103117 / 2200 103118
82070	VALVE	1 CYL.	RUSTON	YDX (30 DEG)	2707 102817 / 2707 103818
82071	VALVE	1 CYL.	RUSTON	YWA	1130 103117 / 1130 103118
82245	VALVE	IN/EX	URSUS	C-330	
82246	VALVE	IN/EX	URSUS	C-360	
82247	VALVE	IN/EX	URSUS	C-385	
82248	VALVE	IN	URSUS	C-385	TURBO
82377	VALVE	IN	ZETOR	2001/3001/4001	950505
82378	VALVE	EX	ZETOR	2001/3001/4001	950506
82043	VALVE		ZETOR	6911 (MODEL-70)	
82061	VALVE	3 CYL.	ZETOR	5911 (4511)	6901 0555 / 6901 0554
82102	VALVE		ZETOR	HINDUSTAN 80 HP	G 804 DI
82713	VALVE	IN	ZETOR HMT	2522 / 327	3272043020/00 - (41.50 X 7.97 X 132.50)
82714	VALVE	EX	ZETOR HMT	2522 / 327	3274303320/00 - (38.00 X 7.97 X 132.50)
82715	VALVE	IN	ZETOR HMT	5911 / 335	3352000060-00 - (44.05 X 9.97 X 129.45)
82716	VALVE	EX	ZETOR HMT	5911 / 335	3352000360-00 - (36.35 X 9.95 X 129.45)
83088	VALVE GUIDE		ROMANIA	U-500, U-650	
83087	VALVE GUIDE		RUSSIAN	BYLARUS (MTZ-50)	
83089	VALVE GUIDE		URSUS		
83080	VALVE GUIDE	IN/EX	ZETOR	8011,8611	100MM
83081	VALVE GUIDE	IN/EX	ZETOR	6911 MODEL 71	
83082	VALVE GUIDE	IN/EX	ZETOR	6911 MODEL 70	
83090	VALVE GUIDE		ZETOR	2011	
83091	VALVE GUIDE		ZETOR	2522	

REH NO.	ITEM		MAKE	MODEL	REF.NO./PART NO./DETAILS
83092	VALVE GUIDE		ZETOR	3011	
83093	VALVE GUIDE		ZETOR	5511	
83094	VALVE GUIDE		ZETOR	5911	
83095	VALVE GUIDE		ZETOR	25-A	
83096	VALVE GUIDE		ZETOR	SUPER 42	
83284	VALVE GUIDE	IN/EX	ZETOR	HINDUSTAN 80 HP	G 804 DI
83344	VALVE GUIDE	IN/EX	ZETOR	URSUS C-360	

VALVE FOR ZETOR	VALVE FOR ZETOR	VALVE FOR ZETOR
		
For ZETOR 6911 – Model 71 THICK SEAT IN – 44 X 9.95 X 129.5 EX – 36.4 X 9.93 X 129.5	For ZETOR 5911 – Model 70 THICK SEAT IN – 39.2 X 7.96 X 130.5 EX – 33.5 X 9.93 X 128.5	For ZETOR 8011 /8611
VALVE GUIDE FOR ZETOR	VALVE GUIDE FOR ZETOR	VALVE GUIDE FOR ZETOR
		
For ZETOR 6911 – Model 71 With Collar IN / EX – 10 X 15 X 64 (Collar 17.6)	For ZETOR 5911 – Model 70 With Collar dia 17.60 mm IN – 7.98 X 15 X 64.8 (Collar 17.6) EX – 9.95 X 15 X 64.8 (Collar 17.6)	For ZETOR 8001 /8601 Without Collar IN – 10.5 X 16 X 68 EX – 10.5 X 16 X 68